



FUTURE FIT[®]
LED KITS

INSTALLATION AND OPERATING INSTRUCTIONS FOR THE FOLLOWING PRODUCTS:

CAT. NO. KT-RKIT12PS-6RP-8CSC

CAT. NO. KT-RKIT30PS-11RP-8CSC-VDIM

INSTALLATION

Product includes the following components:

| PARTS | QUANTITY |
|--------------------------------|----------|
| LED Kit | 1 |
| Installation Instruction Sheet | 1 |
| Hardware Bag | 1 |
| Switch Cover | 2 |

WARNING: Risk of fire or electric shock. Luminaire wiring and electrical parts may be damaged when drilling for installation of LED retrofit kit. Check for enclosed wiring and components.

WARNING: Risk of fire or electric shock. This LED retrofit kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.

WARNING: Risk of fire or electric shock. Install this LED retrofit kit only in luminaires that have the construction features and dimensions shown in the photographs and/or drawings.

WARNING: To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

WARNING: Do not make or alter any open holes of the wiring enclosure or electrical component enclosure during installation. Only those open holes indicated in the photographs and/or drawings may be added or altered as a result of kit installation. Do not leave any other open holes in the wiring enclosure or electrical component enclosure during installation.

Minimum Luminaries Dimensions(KT-RKIT12PS-6RP-8CSC): 10.6”(L) x 4.65”(W) x 2.36”(H).

Minimum Luminaries Dimensions(KT-RKIT30PS-11RP-8CSC-VDIM): 11.8”(L) x 11.8”(W) x 2.76”(H).

CAUTION: Before installing, make certain the AC power to the fixture is off.

CAUTION: The electrical rating of these products is 120-277V. Installer must confirm that there is 120-277V at the fixture before installation.

CAUTION: LEDs are extremely bright. Do not look directly at the LED light source for extended time as over-exposure may cause harm to the eyes.

Installation

1. Read and understand all warnings and notes stated above, before proceeding with retrofit.
2. Check your retrofit kit against parts list.
3. Disconnect Power to Fixture.
4. Remove / Open the fixture's diffuser cover

5. Remove Fluorescent lamps (Dispose of tubes in accordance with current State & Federal regulation.)
6. Remove ballast cover
7. Cut both wires at ballast to the AC
8. Cut the wiring at the lamp holder bases. Remove lamp holders.
9. Remove existing ballast.
10. Use cloth to wipe down the surface of the housing to remove all dust, dirt, etc before proceeding.
11. Use included tek screws to secure the LED kit to the housing using mounting holes. The LED kit should be tightened up against the fixture as close as possible. Installer may drill pilot holes at their discretion to aid in installation.
12. Connect the supply leads form electrical box to the driver lead wire of retrofit kit, using the wire nuts provided. Black leads from the kit connect to the black supply lead, and the white lead from kit connects to the white supply lead. Tighten the wire nuts properly to prevent the wire from coming loose.
13. Switch toggle switches for desired lumen output and color temperature. Place switch covers over switches.

THE RETROFIT KIT IS ACCEPTED AS A COMPONENT OF LUMINAIRE WHERE THE SUITABILITY OF THE COMBINATION SHALL BE DETERMINED BY AUTHORITIES HAVING JURISDICTION.